

Insert angle brackets at each corner. Line up sides and tighten the set screws.

